INCLUDED IN THIS PACKAGE IS THE HARDWARE YOU REQUIRE FOR THE EDSAL WC-1 TOOL CABINET/WORK CENTER.

2 - 10-24 x 3/8" Blind Head Machine Screws

2 - Hex Nuts

12 - Peg Board Hooks

2 - Hasp Lock Handles

YOUR ONLY ASSEMBLY REQUIRES INSERTING HASP LOCK HANDLES THROUGH SLOT IN EACH DOOR (FLAT SIDE AGAINST INNER SURFACE OF EACH DOOR), AND BOLTING WITH MACHINE SCREW AND NUT.